

Instructions for setting eyelets with a Hand closing tool

Important Health & Safety Information

In accordance with the Health and Safety at Work Act 1974, all precautions have been taken as far as is reasonably practicable to ensure that this tool is safe and without risk when used correctly.



(Image may differ from tool supplied)

- Safety gloves should be worn when using this tool.
- Only strike the tool with a rawhide mallet (available through your tool supplier)

Description

The tool is made up of two parts

- The Die (Left)
- The Punch (Far Left)

Instructions

1. Mark out and cut hole to suit eyelet in your material in the desired position (this is best achieved using a hole cutter available from your supplier)
2. Place the die on a sound flat surface.
3. Take an eyelet and place it on to die so the face of the eyelet locates correctly in the recess.
4. Place the material you are setting the eyelet in over the eyelet on the die with the face side of the material down.
5. If used place a ring on top of the material around the barrel of the eyelet.
6. Take the tool punch and insert the end through the eyelet hole and into the body of the die.
7. Holding the punch by the shaft strike the top with a rawhide mallet until the eyelet and ring close tightly around the material and grip it firmly, ensure the punch is vertical (see below)